

Assistance Call System

Compliant
to
VDE_O834



The ASSISTANCE CALL SYSTEM requires the installations of repeaters that cover a wide range of action and allow the correct functioning of HEADBOARD, BATHROOM ALARM and LIGHT ALARM.

It's a wireless system that doesn't need any modification to the electrical system.

It's equipped with a "keep alive" function that every 24 hours verifies if the devices are active.



When the ASSISTANCE CALL is activated through the HEADBOARD or the BATHROOM ALARM, outside of the room the LIGHT ALARM will activate (both sonically and visually) with **GREEN FLASHING LIGHT** to indicate the room of the person who requested assistance and **RED FLASHING LIGHT** to signal the request of medical intervention.

The request of assistance will be visible:

- on **CentroStella** and on the **App** given to the operators with the **type of request**, the **name of the patient**, the **number of the room** and the **time passed since the activation of the call**.



- on the **displays** in the hallways and on the **pager** with the **number of the room** of the patient who requested assistance.

To close the intervention the operator, from the patient's room, will have to press the **SOS** button to signal a critical situation, or the **CANCEL** button to indicate the resolution of the problem.



On CentroStella, it will be possible to download the historization of the operations.